

SPT1 – SPT1 CABLE REPAIR KIT

This kit will repair **two** complete cable breaks or partial cable damage making a weatherproof repair.

- 1) Turn off the lighting system
- 2) Cut the cable ends at 90 degrees to clean them up using a pair scissors or something similar
- 3) Cut 4 equal size pieces of the black heat shrink approx. 10mm long and place each one over each cable end (leaving a little bit hanging over). Heat the heat shrink gently with a cigarette lighter or suitable flame. The heat shrink will shrink down and form a weatherproof end to each cable.
- 4) Open the connector and place both cables in each side of it, leaving just the heat shrink ends hanging out. Push the cables onto the spikes (see pic 1 below)
- 5) Clamp the lid down on the connector until it clicks in place. A pair of pliers maybe needed for this. (see pic 2 below)

